

INSTALLATION OF CONSTANT VOLTAGE-CURRENT GENERATOR

First and foremost, remember this unit must be grounded, or it will not work. Also, it must be installed in an area where nothing could fall or lay against it. The unit could reach 90 degrees.

Recommended Installation:

1. Bugs - under hood.

Remove dash protector, drill 5/16" hole on drivers side of radio - or just behind speaker and mount the unit with wires toward fuse box. Remember unit must be grounded.

Next, you must locate hot lead or power wire to wiper switch. On bugs with fuse panel through fire wall, it should come from last fuse (drivers side). It should be one of the wires (two wires to one clip), one to turn indicator box, the other to wiper switch. When the right wire is determined, cut and strip $\frac{1}{2}$ " off each end. Connect the black wire from it to wiper switch, other wire, red or orange to fuse or power lead. Replace dash protector. Start engine, turn wiper switch on and adjust wiper speed, turn off switch. Do not use this unit for shut off.

2. Station Wagons, Busses and Vans

Install where convenient. Remember, this unit must be grounded.