



# 8912

Hex adapter installs over existing case stud  
Do not over tighten bolts



99-3992



# 8912

Hex adapter installs over existing case stud  
Do not over tighten bolts



99-3992



# 8912

Hex adapter installs over existing case stud  
Do not over tighten bolts



99-3992



# 8912

Hex adapter installs over existing case stud  
Do not over tighten bolts



99-3992



# 8912

Hex adapter installs over existing case stud  
Do not over tighten bolts



99-3992



# 8912

Hex adapter installs over existing case stud  
Do not over tighten bolts



99-3992